

**Construction:**

1. Clear the entrance and exit area of all vegetation, roots, and other objectionable material and properly grade it.
2. Place the stone or other stabilizing material to the specific grade and dimensions shown on the plans, and smooth it.
3. Provide drainage from construction entrance area to carry runoff to a sediment trap or other suitable collection area.
4. Divert construction site runoff away from the construction entrance area to nearby erosion and sediment control measures. Do not allow construction sites to outlet runoff through entrances/exits.
5. When appropriate to do so, use geotextile fabrics underneath construction entrance material to improve stability of the foundation, especially in locations subject to seepage or high water table.

Maintenance:

1. Inspect all measures at least weekly and after each rainfall of 1.0 inch or greater. Make any required repairs immediately.
2. Maintain the stone pad in a condition to prevent mud or sediment from leaving the construction site. This may require periodic tamping with 2-inch stone.
3. Sediment on roadways is to be removed immediately by broom and shovel, either by manual or mechanical means, and not to be washed off where it has the potential to enter a stream, drainage way or storm drain system.